
MACCHINE SELVATICI AGRICOLE

REPLACEMENT PARTS CATALOG

Spading Machine



Series 150.75 (VL)

MG EQUIPMENT COMPANY

Specialized Equipment for Agriculture

EQUIPMENT COMPANY

PO Box 655 - Vineburg, CA 95487

Selvatici Parts Catalog
Spading Machine
Series 150.75 (VL)

MG Equipment Company specializes in unique tractor implements designed specifically for vineyards and orchards.

This catalog is designed to detail all the parts and components for SELVATICI spading machines. It is divided into sections for each of the various parts of the implement and includes exploded diagrams and parts list.

To ensure a long life of reliable and trouble-free service for your implements, use only genuine SELVATICI replacement parts.

It is our goal to meet or exceed the expectations of our customers and to offer unsurpassed service and parts support. We partner with each of our manufacturers to provide the best possible after-sales-support.

We thank you for your valued business. We remain at your complete disposal for any information you require regarding any of our products.

For Replacement Parts Sales and Information contact:

MG Equipment Co.

PO Box 655 Vineburg, CA 95487


mgequipment@gmail.com


Tel: (707) 996-2605

Fax: (707) 996-3405

Mobile: (510) 813-2046

GUIDE TO REPLACEMENT SPADES






Part# ***FS-045-8200 + FS-041-0214***

Model	STANDARD Spade ***Part# FS-339-1001***	WIDE Spade ***Part# FS-339-1002***
VL-1104	**-**	**4 pcs**
VN-1356	**6 pcs**	**-**
VN-1506	**6 pcs**	**-**
VN-1656	**-**	**6 pcs**
VN-1808	**8 pcs**	**-**
VN-2008	**8 pcs**	**-**

For technical questions or to order parts, please call: ***(510) 813-2046 or (707) 996-2605***


GEAR BOX ASSEMBLY



Item#	Part#	Description
1	FS-333-0000	Main gearbox - series 75/80/95
2	FS-025-0010	Pressure relief cap - ½"
3	FS-030-0600	Bearing 30309 (45-100-27.25)
4	FS-330-2325	Shaft + gear (2 pcs) - series 75/80/95 - Z9 x 29 M8.2
5	FS-349-0100	Spacing collar - 41 x 51 x H44
10	FS-030-0100	Bearing 33109 (45-80-26)
11	FS-331-1745	Main driveshaft - PTO spline groove - series 75/80/90 - L=745
12	FS-021-0801	Oil seal BASL 80 x 40 x 10
13	FS-030-0450	Bearing 32211 (55-10-26.75)
14	FS-349-0120	Spacing collar - 56 x 76 x H55
15	FS-330-1000	Driveshaft - central - series 150.75-95 D55
16	FS-349-0710	Spacer - 89 x 99 x 0.3
	FS-349-0720	Spacer - 89 x 99 x 0.5
	FS-349-0730	Spacer - 89 x 99 x 1.0

Item#	Part#	Description
17	FS-335-1000	Side cover plate - series 75/80/95
18	FS-040-0110	Star washer - 10 mm DIN 6798/A
19	FS-044-5600	Bolt - M10 x 1.5 x 30 UNI 5739 - 8.8
20	FS-020-1000	Oil seal BA 100 x 85 x 7
21	FS-021-1101	Oil seal BASL 110 x 85 x 12
51	FS-349-0260	Spacing ring - 44 x 63 x H7
52	FS-323-1000	Spline groove sprocket arm plate D85 R120 H48
	FS-342-3000	Spline groove sprocket arm plate D85 R150 H61
53	FS-010-0165	O-Ring 165 int - 61.91 sp. 3.53
54	FS-316-3045	Nut - M40 x 2 H17E7
55	FS-045-0200	Bolt - M6 x 1 x 16 UNI 5931 - 8.8
58	FS-024-0010	Aluminum washer - ½"


GEAR BOX ASSEMBLY



Item#	Part#	Description
6	FS-030-0100	Bearing 33109 (45-80-26)
7	FS-041-0945	Locking nut - M45 x 1.5 H=10
8	FS-047-0045	Tab-locking washer MB 9 D.45
9	FS-041-0145	Locking nut - M45 x 1.5 H=16.5
10	FS-030-0100	Bearing 33109 (45-80-26)
18	FS-040-0110	Star washer - 10 DIN 6798/A
19	FS-044-5600	Bolt - M10 x 1.5 x 30 UNI 5739 - 8.8
22	FS-332-1000	Secondary gearbox - series 75/80/95
23	FS-341-4000	Threaded rod - gear selector shuttle - series 75/80/95
24	FS-352-1000	Gear selector - series 75/80/95
25	FS-331-1315	Sliding gear Z=13 + Z=15 - Mod.7
26	FS-010-2031	O-Ring 2031 - int 7.65 sp. 1.78
27	FS-204-4000	Spring
28	FS-607-3000	Selecting pin
29	FS-341-3000	Spring tensioning nut - series 75/80/95
30	FS-047-6008	Plastic ball - M8 x 1.25 - diam. 25
31	FS-349-5040	Spacing collar - 43 x 54 H13
32	FS-331-3013	Gear - Z=13 - H25 D114
33	FS-349-5030	Spacing collar - 43 x 54 H27.5

Item#	Part#	Description
34	FS-331-3015	Gear - Z=15 - H25 D116
35	FS-349-5020	Spacing collar - 43 x 54 H107.5
36	FS-331-3016	Gear - Z=16 - H25 D129
37	FS-349-5050	Spacing collar - 43 x 54 H6
39	FS-040-2012	Flat washer - 12 x 36 x 2.5 - zinc coated
40	FS-352-2000	Bracket (internal) - series 75/80/95 KG 0.336
41	FS-341-5000	Fulcrum for gear lever
42	FS-010-3081	O-Ring 3081 - int 20.24 sp. 2.62
43	FS-352-3000	Lever - gearbox speed control
44	FS-041-0212	Self-locking nut - M12 x 1.75 H14.5 - 6.8
45	FS-341-6000	Bolt for fulcrum - M10 x 1.5
46	FS-032-0040	Bearing 6307 (35-80-21)
47	FS-335-2000	Gearbox cover plate - series 75/80/95
48	FS-040-2018	Flat washer - 18 x 54 - zinc coated
49	FS-041-0218	Nut (self-locking) - M18 x 2.5 H21 - 6.8
50	FS-045-2230	Bolt - M10 x 1.5 x 50 UNI 5933 - 10.9
56	FS-024-0500	Copper washer - 3/8"
57	FS-025-0030	Oil plug - 3/8"


BODY / FRAME



Item#	Part#	Description
1	FS-381-104L	Main body/frame - Series 150.75 - Model 1104
2	FS-041-0220	Nut (self-locking) - M20 x 2.5 x H22 - 6.8
3	FS-310-3010	Support plate - series 150.75 - int 280
4	FS-387-6000	Dust cover - 20 x 67
5	FS-020-0470	Oil seal BA 47 x 30 x 7
6	FS-387-5000	Spacer - 20 x 30 x 10
7	FS-032-0250	Bearing 6204 (20-47-14)
8	FS-387-4000	Spacer - 21 x 34 x 34.4
9	FS-387-2000	Pin support assembly - Series B - 150.75

Item#	Part#	Description
9A	FS-387-2500	Complete support assembly - 150.75 (2+4+5+6+7+8+9+10+14)
10	FS-044-0270	Bolt - M20 x 2.5 x 170 UNI 5737 - 8.8
11	FS-044-0840	Bolt - M14 x 2 x 70 UNI 5737 - 8.8
12	FS-041-0416	Nut (self-locking) - M16 x 1.5 x H17.5 - 6.8
13	FS-041-0214	Nut (self-locking) - M14 x 2 x H16 - 6.8
14	FS-026-0010	Grease fitting - M10 x 1.5 (hexagonal head)
15	FS-043-0450	Bolt - M16 x 1.5 x 55 UNI 5738 - 8.8
16	FS-309-7000	Link pin - 22/28 mm
17	FS-046-8005	R-clip - 5 x 100


SPADING ARMS / BEARINGS



Item#	Part#	Description
1	FS-309-3000	Crown nut (locking) - M38 x 2 x H18 E55
2	FS-046-2400	Spring pin - 5 x 55
3	FS-309-1097	Dust cover - 40 x 97 (steel)
4	FS-020-0800	Oil seal - BA 80 x 60 x 10
5	FS-309-2000	Spacing collar - 40 x 60 x 10.5 Est.Testa d80/90
6	FS-032-0220	Bearing 6208 (40-80-18)
7	FS-324-4000	Spacing collar - 40 x 50 x 14 Int. Testa d80
8	FS-386-1000	Spading arm (straight) - series 150.75
9	FS-026-0010	Grease fitting - M10 x 1.5 (hexagonal head)
10	-----> (see Spading Sprocket Selection Guide - page 7)	
11	FS-336-1122	Bolt - M38 x 2 x L=122
12	FS-041-0220	Nut (self-locking) - M20 x 2.5 x H22 - 6.8
13	FS-387-4000	Spacing collar - 21 x 34 x H34.4
14	FS-032-0250	Bearing 6204 (20-47-14)
15	FS-387-5000	Spacing collar - 20 x 30 x 10
16	FS-020-0470	Oil seal - BA 47 x 30 x 7
17	FS-387-6000	Dust cover - 20 x 67 (steel)
18	FS-310-3010	Support strap - series 150.75 - int 280
19	FS-044-0220	Bolt - M20 x 2.5 x 140 UNI 5737 - 8.8
20	FS-044-5650	Bolt - M10 x 1.5 x 14 UNI 5739 - 8.8

Item#	Part#	Description
21	FS-041-0530	Nut (self-locking) - M30 x 2 x H25 - 6.8
	FS-041-0430	Nut (self-locking) - M30 x 2 x H32 - 6.8
22	FS-026-0010	Grease fitting - M10 x 1.5 (hexagonal head)
23	FS-347-1001	Sealing cap (threaded) - 60 x 110 x 22
24	FS-020-1001	Oil seal - BA 100 x 85 x 9
25	FS-032-0210	Bearing 6212 (60 x 110 x 22)
26	FS-347-2001	Support collar - 60 x 110 x 22
27	FS-045-0200	Bolt - M6 x 1 x 16 UNI 5931 - 8.8 (allen hex head)
28	FS-338-3000	Key - 14 x 12 x 25
29	FS-043-0250	Bolt - M30 x 2 x 135 UNI 5738 - 8.8
	FS-043-0240	Bolt - M30 x 2 x 140 UNI 5738 - 8.8
30	FS-386-2001	Spading arm (LEFT side) - series 150.75
31	FS-309-8000	Nut - M38 x 2 x H20 - E55
32	FS-386-2000	Spading arm (RIGHT side) - series 150.75
33	FS-045-8200	Bolt - M14 x 2 x 70 UNI 5737 - 8.8 - Zinc coated
34	FS-041-0214	Nut (self-locking) - M14 x 2 x H16 - 6.8
35	-----> (see Spading Sprocket Selection Guide - page 7)	
36	FS-336-1136	Bolt - M38 x 2 x L=136
37	FS-339-1002	Spade - wide 150 - 200h230 (model 1104/1656)

3-POINT / PROTECTIVE SHIELDS




Item#	Part#	Description
1	FS-389-3000	Top 3-point strap - series 150.75
2	FS-041-0214	Nut (self-locking) - M14 x 2 x H16 - 6.8
3	FS-336-2000	U-bolt - M14 x 2
4	FS-388-1029	Upper cover plate - series 150.75 - Model 1104
5	FS-388-2029	Lower cover plate/flap - series 150.75 - Model 1104
6	FS-046-8004	R-clip - 4 x 80
7	FS-410-4080	L-pin - D.14 L=75
8	FS-311-3108	Cover hinge pin - Model 1104
9	FS-044-6200	Bolt - M14 x 2 x 35 UNI 5739 - 8.8 - Zinc coated
10	FS-388-5080	Side protective plate (Left or Right) - series 150.75
11	FS-041-0214	Nut (self-locking) - M14 x 2 x H16 - 6.8
12	FS-320-1013	Skid + adjustable support arm - Series 120.45/150.75-90
13	FS-309-5018	L-pin - D.18 L=70
14	FS-046-8005	R-clip - 5 x 100

Item#	Part#	Description
15	FS-041-0222	Nut (self-locking) - M22 x 2.5 x H25 - 6.8
16	FS-044-6600	Bolt - M22 x 2.5 x 60 UNI 5739 - 8.8 - Zinc coated
17	FS-389-5016	3-point frame strap (Left side) - series 150.75/95
18	FS-389-5006	3-point frame strap (Right side) - series 150.75/95
19	FS-044-1610	Bolt - M22 x 2.5 x 110 UNI 5737 - 8.8 - Zinc coated
20	FS-041-0222	Nut (self-locking) - M22 x 2.5 x H25 - 6.8
21	FS-309-6000	Link pin - 19/25 mm
22	FS-044-6610	Bolt - M22 x 2.5 x 65 UNI 5739 - 8.8 - Zinc coated
23	FS-389-6035	Spacing collar - 23 x 38
24	FS-040-2016	Flat washer - 16 x 48 x 4 - Zinc coated
25	FS-044-5220	Bolt - M16 x 2 x 40 UNI 5739 - 8.8 - Zinc coated
26	FS-050-0000	PTO shield - oval shaped (plastic)
27	FS-044-5810	Bolt - M8 x 1.25 x 25 UNI 5739 - 8.8 - Zinc coated
31	FS-040-0108	Star washer 8 mm


SELECTION GUIDE FOR SPADING ARM SPROCKETS

Model: VL-1104 (4 spades)



Note: LEFT and RIGHT are determined when standing behind the implement when attached to the tractor.

Item#	Part#	Specifications
A	FS-323-1000	Sprocket Plate - d = 85 / r = 120 / h = 48
B	FS-342-3000	Sprocket Plate - d = 85 / r = 150 / h = 61
C	FS-338-4015	Sprocket Arm - a = 15 / r = 150 / h = 62
D	FS-338-4027	Sprocket Arm - a = 27 / r = 150 / h = 62
E	FS-338-4044	Sprocket Arm - a = 45 / r = 150 / h = 62
F	FS-338-4075	Sprocket Arm - a = 75 / r = 150 / h = 62
G	FS-343-4015	Sprocket Arm - a = 15 / r = 150 / h = 74.5
H	FS-343-4027	Sprocket Arm - a = 27 / r = 150 / h = 74.5
I	FS-343-4044	Sprocket Arm - a = 45 / r = 150 / h = 74.5
J	FS-343-4075	Sprocket Arm - a = 75 / r = 150 / h = 74.5
K	FS-338-4045	Sprocket Arm - a = 45 / r = 150 / h = 62
L	FS-343-4045	Sprocket Arm - a = 45 / r = 150 / h = 74.5
Item#	Part#	Specifications
---	FS-386-1000	Spading Arm (Straight) - series 150.75
2+4	FS-386-2000	Spading Arm (RIGHT side) - series 150.75
1+3	FS-386-2001	Spading Arm (LEFT side) - series 150.75





For Questions or Technical Assistance Contact:

MG Equipment Co.

PO Box 655
Vineburg, CA 95487
Tel: (707) 996-2605
Mobile: (510) 813-2046
mgequipment@gmail.com

REV-1612